

Framery Cleaning Guide



1. Exterior Panels

Wipe the metal exterior panels using a mild alkaline all-purpose detergent.

2. Frames, Tabletops and Door Handles

Use a mild alkaline all-purpose detergent or an alcohol-based disinfectant.

In extreme circumstances, a 1% chlorine-based solution may be used for tabletops. Apply a small amount of the solution to a cloth and wipe the surface gently. Avoid rubbing, as it may cause discoloration.

3. Carpet, Upholstery, and Interiors

We use wool in our fabrics, which is naturally dirt-resistant. We recommend dry cleaning or professional cleaning for woollen textiles. Washing is not recommended.

Alcohol-based disinfectants can be used without damaging the textiles or changing its colour. Concentration should be between 70-85%. Avoid chlorine-based and bleach cleanable solutions.

Our highly pilling-resistant wool-blend fabric may initially experience a "first lint" phase. This is a natural process where short staple fibers work their way out of the yarn. After safely removing this lint, the fabric stays pill-free.

To remove the lint, stretch the fabric flat and use a battery-operated fabric shaver (lint shaver) in gentle, circular motions. Avoid pressing hard, and do not use manual razors, which can tear the underlying wool fibers.

Interior panels can be vacuumed.

4. Glasses

Glass surfaces can be cleaned with a standard glass cleaning solution.

5. Ventilation Shafts

Vacuum the ventilation shaft in the Framery One. For the other smart pods, gently vacuum the lighting grills (the ventilation shafts are located behind them).

6. Touchscreens

Gently wipe the screen with a damp microfiber cloth.